

# Welding

## 6013 do's & don't

- Work on clean metal. It's not a deep penetration rod and therefore does not burn through surface contaminants very well.
- In T-joint hold rod 30-35 degrees from horizontal plane, to make sure that enough is deposit on the vertical plane. Gravity will take care of horizontal plane
- Having a slag stringer in the start of a 6013 bead is very common. What you are seeing is the heavy flux on top of the weld pool, and not molten metal. Getting a slightly slower start to the weld bead will solve this problem. A little hesitation before moving the rod will give the puddle time to bridge between both surfaces and solve this problem.

## Alternatives

- 6010
- 7018 (7016)

From:

<https://wiki.oscardegrout.nl/> - HomeWiki



Permanent link:

<https://wiki.oscardegrout.nl/doku.php?id=other:welding&rev=1667635357>

Last update: **2022/11/05 08:02**