

Build Commands

Core tools

Esp-idf commands can be executed using:

- **idf.py**, Located in: `/esp32/esp-idf/tools/idf.py`
- **python**, Located in: `/esp32/idf-tools/python_env/idf5.2_py3.11_env/bin/python`
- **esptool.py**, Located in: `/esp32/idf-tools/python_env/idf5.2_py3.11_env/bin/esptool.py`

Common Build commands

```
idf.py --version  
idf.py help  
idf.py menuconfig  
idf.py fullclean  
idf.py build
```

From:

<https://wiki.oscardegroot.nl/> - HomeWiki

Permanent link:

<https://wiki.oscardegroot.nl/doku.php?id=esp:esp32:build-commands&rev=1788006411>

Last update: **2026/08/29 12:26**

