

# Build Commands

---

## Core tools

Esp-idf commands can be executed using:

- **python**, Located in: `/esp32/idf-tools/python_env/idf5.2_py3.11_env/bin/python`
- **idf.py**, Located in: `/esp32/esp-idf/tools/idf.py`
- **esptool.py**, Located in: `/esp32/idf-tools/python_env/idf5.2_py3.11_env/bin/esptool.py`

**idf.py** to be invoked as:

```
$ idf.py <parameters>
```

## Common Build commands

```
idf.py --version  
idf.py help  
idf.py menuconfig  
idf.py fullclean  
idf.py build
```

From:

<https://wiki.oscardegroot.nl/> - HomeWiki

Permanent link:

<https://wiki.oscardegroot.nl/doku.php?id=esp:esp32:build-commands&rev=1788009466>

Last update: **2026/08/29 13:17**

