

Build Commands

Core tools

Esp-idf commands can be executed using:

- **idf.py**, Located in: ./esp32/esp-idf/tools/idf.py/
- **python**, Located in: ./esp32/idf-tools/python_env/idf6.1_py3.13_env/bin/python
- **esptool**, Located in: ./esp32/idf-tools/python_env/idf6.1_py3.13_env/bin/esptool

Common Build commands

- idf.py -version - idf.py help - idf.py menuconfig - idf.py fullclean - idf.py build

From:

<https://wiki.oscardegroot.nl/> - HomeWiki

Permanent link:

<https://wiki.oscardegroot.nl/doku.php?id=esp:esp32:build-commands&rev=1789208279>

Last update: **2026/09/12 10:17**

